

# Important notice regarding VPT24-1PZ and Daylight Saving Time

The VPT24-1PZ model has two programming modes: STD (Standard) and PRO. There is a setting that can be enabled in the PRO programming mode that will automatically adjust for Daylight Saving Time (DST). If that setting was not enabled or if the device was set up in STD (Standard) Mode, you will need to manually adjust the time on the clock twice a year or enable the Daylight Saving Time feature.

## There are two options for Daylight Saving Time:

### 1) Short-Term Solution - Manually change the time

- a. If the clock did not automatically adjust with Daylight Saving Time, the time will need to be manually changed.
  1. Place your fingers on the bottom of the switch paddle and gently lift it upward to open it until it clicks.
  2. Press the MENU button until you see CLK appear and press the SET button.
  3. Adjust the time using the UP or DOWN arrows and press the SET button after each setting.



**NOTE:** This solution requires that the time be manually adjusted twice a year after Daylight Saving Time.

### 2) Long-Term Solution - Reset and Reprogram in PRO Mode enabling the DST setting

- a. To Reset and Reprogram in PRO mode, visit [www.leviton.com/vpt24](http://www.leviton.com/vpt24)
  1. Scroll down to the video named PRO Programming for step-by-step instruction.
  2. The Supports/Downloads tab contains an instruction sheet with step-by-step instruction on how to reset the clock.